

# THERMOMASTER THERMAL INSULATION SYSTEMS

## SYSTEM SETUP AND GENERAL RULES OF INSTALLATION



- 1 ISOMASTER EPS H80 G Silver insulation board
- 2 THERMOMASTER FIX PREMIUM adhesive and base coat
- 3 MASTERNET PREMIUM 160 fiberglass mesh
- 4 THERMOMASTER primer (key coat)
- 5 THERMOMASTER acrylic or silicone render (finishing coat)

### Socle insulation system

- 6 ISOMASTER XPS insulation board
- 2 THERMOMASTER FIX PREMIUM adhesive and base coat
- 7 THERMOMASTER Socle profile
- 8 THERMOMASTER MOSAIC marble plaster

### THERMOMASTER insulation system accessories

- 9 THERMOMASTER dowels
- 10 THERMOMASTER corner bead with mesh
- 11 THERMOMASTER PUR adhesive foam
- 12 THERMOMASTER W-PROF window connection profile
- 13 Hammer fix dowel
- 14 EJOT spiral anchor
- 15 EJOT profile connector
- 16 EJOT plastic spacer for socle profile