

TENMAT Socket Box Inserts

Installation Instructions

TENMAT Socket Box Inserts are designed to improve air tightness while reinstating the fire integrity and insulation of a plasterboard partition.

If you are unsure about any details within this method statement, please email tech@pfc-corofil.com

General

- Ensure the socket box insert is the correct size for the socket box
- Ensure partition is a minimum 120mm thick 120 minute integrity rated plasterboard partition
- Make a small tight fitting hole through the insert to accept the cable(s)
- Pass the cable through the insert and fit the insert into the socket box
- Fit the socket cover over the socket box insert. The screws will pass through the fibre
- The flange of the insert should be hidden by the socket cover.

Health & Safety Instructions

Please refer to SDTSBI

Other Information

Please ensure the product(s) described within this method statement have been tested in, and are suitable for your application.

Doc Reference				MSTSBI			
PB	SE	CB	CI	AB			
This Copy				Review Date			
May 2018				May 2020			